

Programming the ResponseCard® IR



Set ResponseCard® to a Programmable ID:

1. Press and hold the "*" and "6" buttons simultaneously for 3 seconds. LED will turn solid red to indicate the process was performed correctly.
2. Enter the number you would like to program the ResponseCard with waiting for the LED to flash after each digit of the number is entered. i.e. - If you would like to set the ResponseCard to the number 32, perform the process in Step 1 above and press the number 3 (the LED will flash to indicate digit was programmed), then enter the number 2 (the LED will flash again to indicate the next digit was programmed).
3. Press the "*" button and the LED will flash 3 times to indicate that the ResponseCard was successfully programmed to a numeric value.