


Programming the ResponseCard® XL



Set ResponseCard® to a Programmable ID:

1. Press and hold the “*” and “6” buttons simultaneously for 3 seconds. The LED will turn solid red, and the display will read “Select User ID” to indicate that step 1 was performed correctly.
2. Enter your 6 digit number that you would like to program the ResponseCard with waiting for the LED to flash after each digit of the number is entered.
(ie. User ID 1 = 000001, User ID 21 = 000021)
The red light should flash as each number is entered.
3. After the final number is entered, the LED will flash 3 times to indicate that the ResponseCard was successfully programmed to a numeric value.