

ResponseCard XL User Guide

(To use your ResponseCard XL with a regular TurningPoint Presentation, you respond the same way as the ResponseCard IR.)

To use your ResponseCard XL with TurningPoint XL, press the “T/P” button on the keypad.

Your screen will say “Enter Control # or 000.”

- If you have a version of the test that has been randomized by the instructor, you will have a control number located in the upper left-hand corner of the test.
- If you do not have a randomized version of the test you will enter “000.”
- Enter your control number and wait for your screen to change.



Your next screen will look like this:

Question Number Your Answer
001 |
TEST

- Press the button on the keypad that corresponds with the answer you have chosen for question 1.
- Example

If you chose Answer option 3 your screen will look like this:

Question Number Your Answer
001 | 3
TEST

If you do not know the answer to a question and would like to come back to it later you can skip that question by pressing the “NO / ↓” button to advance to the next question.

To come back to that question at another time you can press the “YES / ↑” button to return to the skipped question.

To jump to a question closer to the end of the test, press the * button. Your question number will start to blink. You can then type in the number of the question you wish to answer. For example, if you were going to question 070 from question 003 you would do the following:

Press *

Type in 070 for question 70

Press the ? button to return to answer mode

You can now answer question 70

Your answers will still be stored in the keypad and you have the option to go back and change your answers as well.

Once you have completed your test, you will need to transfer your answers to the teacher's computer.

- To do this press the "T/P" button.
- Your screen will say "Leave Test Mode? (Y/N)." Press the "YES" button on the keypad.
- You will then get a screen that says "Press * & ? to transmit Stored Data LOCK. You will need to aim the keypad at the receiver and press the * key and the ? key at the same time. You must be within 3 feet of the receiver to transmit responses.
- Your next screen will say "Press T/P to Clear Stored Data LOCK. Press the T/P button.
- Your will next screen will say "Erase Stored Data? (Y/N)." Press "YES" to clear the data so that the keypad is ready to accept answers for another test.

Depending upon the teacher's preferences you may receive a visual or aural confirmation that your response was received.

TO PROGRAM THE KEYPAD TO A SPECIFIC NUMBER:

Hold down the * and the 6 buttons at the same time until your screen displays "SELECT USER ID"

If you are programming the keypad to number 21 you will need to enter 4 0's before the 21. The programmed ID but contains 6 digits. For example:

000001

000021

000132

Once 6 digits are entered into the keypad, the LED light will flash red 3 times to acknowledge that the keypad has been successfully programmed. Your screen will then go blank.

To make the keypad a fixed ID, and set it back to the default, you need to press * & 1 at the same time. Your screen will display "INIT ID DEFAULT." This lets you know that the keypad is back to the default setting.